

Step 14



Insert the insulation to a depth of 50mm (the height of the braces).

Step 15



Cover the whole of the inside of the box with metal foil and staple it to the wood.

Step 16



Taking care that there is no gap between the insulation layer and collector surface, place the pipework (with fins) on top.

Step 17



Fasten the pipes down on to the corner braces using the pipeclips (photo before).